




ZWF Hydraulic Wedge Jacks Parts Breakdown

Toll Free: 1-800-579-8088 Web: www.zinko.com

REV 070209



Part #	Description
01	Complete Oil Block
09S	Pressure Gauge Set Including #2,3,7,8,9,10
09	Pressure Gauge
23	* O-Ring
28	Screw M8 x 18L
29	Screw Ø10
30	Base Plate
31	Top Plate
32	Spreader
33	* O-Ring
34	Oil Bag inner packing
35	* Packing
36	* Back up Ring
37	* Tube Stopper
38	Piston Rod
39	Return Tube Cylinder
40	* Back up Ring

Part #	Description
41	* O-Ring
42	Packing
43	* O-Ring
44	* Back up Ring
45	* O-Ring
46	Oil Bag
47	Rod
48	Cylinder
49	* O-Ring
50	Spreader Mounting
51	* O-Ring
52	* Back up Ring
53	Top Cap
54	Dust Seal
55	C Ring
56	Spreader
57	Cushion
58	Scerw M8 x 8L

Part #	Description
59	Handle
60	Carrying Handle
88S	Handle Socket accessory Including #61,62,63,66 67,68,69,70,71,72,73 74,75,76,87,88,90
85	Wear-Resistant Ring
86	Oil Bag Outer Packing
87	Screw M5 x 16L
88	Handle Socket
89	Screw M6 x 10L
90	Spring
92	Screw M5 x 6L
93	Wear-Resistant Ring
96	Screw M6 x 16L
97	Base cover
RP	Repair Kits (All *)